



Index PDF	Référence	Designation commerciale
A	103700S	CIRCUIT BOARD
M	303105S	MOTOR CL60D BF 400/50/3
1	39681	STAINLESS STEEL BULK FEED HEAD
2	29928	BULK FEED HEAD W/OUT TRAY
3	29925	LID LATCH ASSEMBLY
4	117774S	[Spare parts translation not found]
5	117775S	[Spare parts translation not found]
6	39705	SHOULDERED RING X2
7	117777S	[Spare parts translation not found]
8	117200S	[Spare parts translation not found]
9	117809S	CONTROL BOARD SUPPORT
10	117813S	CONTROL BOARD
11	29533	PCB SUPPORT ASSEMBLY
12	29903	[Spare parts translation not found]
13	118586S	[Spare parts translation not found]
14	403979S	[Spare parts translation not found]
15	502170S	I BUTTON
16	503268S	ASS BUTTON II
17	502169S	STOP BUTTON
18	118850S	[Spare parts translation not found]
19	118849S	[Spare parts translation not found]
20	29907	SEALING SOCKET ASSEMBLY
21	29906	SEAL ASSEMBLY
22	129451S	SAFETY SWITCH 87-53 1A66 CUTTER
23	118527S	[Spare parts translation not found]
24	200008S	[Spare parts translation not found]

25	118584S	[Spare parts translation not found]
26	203157S	[Spare parts translation not found]
27	118585S	[Spare parts translation not found]
28	39087	RUBBER LID STOP
29	29915	SHAFT ASSEMBLY
30	504328S	[Spare parts translation not found]
31	39680	PUSHER FEED HEAD CL60E
32	39684	PUSHER FEED HEAD HANDLE CL60E
33	39663	CL52E PUSHER ABUTMENT
34	39672	CL52E RING OF SLIDING
35	39664	SHOULDERED RINGS (Qty=2)
36	39665	BACK TIEROD
37	39666	CL52E AXLE 8x40
38	39667	AXLE 8x50
39	39668	CL52E PUSHER GUIDE ASSEMBLY
40	49221	EXACTITUBE CL52-CL55-CL60-R652
41	39671	CL52E MAGNET HOLDER ASSEMBLY
42	39669	CL52E VEGETABLE PUSHER ASSEMBLY
43	39660	CL52E REMOVABLE WALL
44	39670	CL52E SHOULDERED RINGS 18x25 (Qty=2)
45	29692	GROOVER ASSEMBLY
47	29156	FEEDING CONE ASSEMBLY
48	49527	GOUGE WRENCH R502G-R502VVG-R752-R752VV
49	102690S	SLING PLATE
50	29706	PUSHER STOP ASSEMBLY
51	117321S	[Spare parts translation not found]
52	118420S	CABBAGE EJECTING PLATE

53	39682	HANDLE
54	407295S	[Spare parts translation not found]
55	118582S	[Spare parts translation not found]
56	503272S	[Spare parts translation not found]
57	39071	STOP POWER CORD ASSEMBLY
58	39683	MOTOR HOUSING FRAME ASSEMBLY
59	29914	LID LATCH SAFETY SWITCH ASSEMBLY
60	29908	WHEEL ASSEMBLY
61	118566S	[Spare parts translation not found]
62	118567S	[Spare parts translation not found]
63	118565S	[Spare parts translation not found]
64	203157S	[Spare parts translation not found]
65	100869S	[Spare parts translation not found]
66	118529S	[Spare parts translation not found]
67	29931	[Spare parts translation not found]
68	500845S	[Spare parts translation not found]
69	29058	SHOULDERED RING ASSEMBLY (2)
70	39318	CONTAINER 1/4
71	49176	LOCKING KNOB
72	49177	[Spare parts translation not found]
73	49178	ADJUSTABLE RUBBER FOOT