




Pos	Code	Description
0001	70146	BIG HOPPER LID
0002	70145	HOPPER SHUTTER
0003	90166	BIG HOPPER WITH SHUTTER
0004	90325	DISPLAY SUPPORT
0005	50271	TOUCH SCREEN
0006	50276	SERIAL CONNECTOR
0007	45323	NUT
0008	90180	SWITCH ASSEMBLY
0009	20365	BRACKET
0010	75548	FILTER-HOLDER REST
0011	40246	PIN
0012	70163	TRAY
0013	70173	RUBBER PEG
0014	70150	HOPPER SUPPORT
0015	90501	ADJUSTMENT LEVER
0016	90338	HEAD ASSEMBLY
0017	75554	GASKET
0018	912086	SCREW
0019	90301	BURRS
0020	45132	NUT
0021	746822	WASHER
0022	10257	DRIVE HUB
0023	45516	FLAP
0024	70165	SPOUT RUBBER ELEMENT
0025	90337	MOTOR ASSEMBLY
0026	20387	SPOUT
0027	75158	BUFFER
0028	50336	WIRING
0029	80128	BOX
0030	50108	SWITCH
0031	10485	GRINDER BODY
0032	50161	CORD CLAMP
0033	20334	BRACKET
0034	75205	PIN
0035	90457	MICROSWITCH
0036	75146	PIN
0037	20332	BRACKET
0038	75164	SUPPORT
0039	50286	ELECTRONIC BOARD
0040	50192	CAPACITOR
0041	20333	PLATE
0042	70138	FOOT
0043	50213	CORD